

Premier V-Neck Jumper — Measuring Guide

Chest (At 2cm from under arm)

Measure around the fullest part of the chest, making sure that the tape is 2cm from under the arms and mid-way across the shoulder blades.

Front Length (Side Neck Point to Hem)


Measure from the side neck point of the shoulder down to the hemline.

Sleeve Length (Left Sleeve and Including cuff)

Measure from the point where the shoulder seam and neck opening meet down to the end of the cuff.

** Please note these are chest body measurements*

To Fit Chest (Inches)	24"	26"	28"	30"	32"	34"	36"	38"	40"	42"	44"	46"
Chest (cm)*	61.0	66.0	71.0	76.0	81.5	86.5	91.5	96.5	102.0	107.0	112.0	117.0
Front Length (cm)	44.5	47.5	51.0	54.5	57.5	61.5	65.0	69.0	72.0	74.0	76.0	78.0
Sleeve Length (cm)	47.0	51.0	54.5	59.5	63.5	67.0	71.0	74.0	76.0	78.5	80.5	82.5



PREMIER V-NECK JUMPER AAAA112033—1WW